

1. Lower the bottom edge of the shade until it is approximately 5 inches above the ground.
2. Align the front and rear steel bars with the three mounting holes on the hem bar.
3. Attach the front and rear steel bars to the hem bar:
 - a. Begin by securing one end of the steel bars with one of the three provided weight bar screws. Leave the screw slightly loose.
 - b. Secure the opposite end with another weight bar screw, also leaving it slightly loose.
 - c. Install the third screw in the center. Once all three screws are in place, tighten them securely.

